# BOAT REMOTE™ QUICK REFERENCE GUIDE

## COMMAND SUMMARY

**TEMP#1, #2, & #3**

High Limit: +160 deg F max.
Low Limit: -20 deg F min.
Mode: On, Off, Status-Only
Rec Time: 0m, 0s - 999m, 59s
Phone Selection: 1-8

**AC POWER**

Mode: On, Off, Status-Only
Rec Time: 0m, 0s - 999m, 59s
Phone Selection: 1-8

**HIGH WATER**

Mode: On, Off Status-Only
Rec Time: 0m, 0s - 999m, 59s
Phone Selection: 1 - 8

**BATTERY**

High Limit: 16V max.
Low Limit: 0V min.
Mode: On, Off, Status-Only
Rec Time: 0m, 0s - 999m, 59s
Phone Selection: 1-8

**BILGE #1 & #2**

Mode: On, Off, Status-Only
Run Time: (0=disabled), 999m, 59s
Cyc/Hr: (0=disabled), 1-120cyc/1-24hrs
Phone Selection: 1 - 8
Data Reset: Y/N

**AUXILIARY**

Mode: On, Off, Status-Only
Rec Time: 0m, 0s - 999m, 59s
Normality: Open/Closed
Phone Selection: 1-8

**SYSTEM**

Max Calls: 1-255
Call Delay: 0m, 0s - 999m, 59s
Intercall Delay: 0m, 30s - 999m, 59s
Dialing Method: Pulse/ Tone
TAD: On/Off
Voice Reps: 1 - 10
Rings til Answer: 1 - 255
Listen-In: 0 - 255s

Speaker: On/Off
Temp Scale: deg F/deg C
Output Trigger: All, Security-Only
Output Mode: Away, Away/Onboard
Current Time: xx:xx (military)
Today's Date: month/day

**SECURITY**

Mode: On, Off, Status-Only
Rec Time: 0m, 0s - 999m, 59s
Normality: Open/ Closed
Phone Selection: 1 -8

### MODE Key

1) Toggles between Standby, Onboard & Away modes.
2) Toggles between parameter options from within a menu.

### ENTER Key

Used to enter programming changes or to clear parameters.

### DOWN ARROW Key

1) Scrolls through the idle status screens.
2) Used to move through menu options without changing programming parameters.

### UP ARROW Key

1) Scrolls through the idle status screens.
2) Used as a backspace key when entering phone number or dialout selection.

### CODE Key

1) Used to insert a decimal point.
2) Used to program special dialing options within a phone number.

CODE 1 = W, wait til answer
CODE 2 = P, pause for 2 seconds
CODE 3 = V, give voice report and hangup
CODE 4 = #, hangup the call
CODE 5 = D, wait for dial tone

**Phonetics, Inc.** MARINE DIVISION, 901 Tryens Road, Aston, PA 19014 Phone: (610) 558-2700 FAX: (610) 558-0222
http://www.sensaphone.com